



RUSTLER 4x4 ULTIMATE

KAROSSERIE MONTAGE



REV 230809-R02

TRAXXAS

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

See Parts List for a complete listing of optional accessories.



TRX1747G
TRX1747R
NL M4x0.7 Flanged
TRX1747A
TRX1747P
TRX1747T
TRX3647

TRX6837G
TRX6837X
TRX6837A
TRX6837R
TRX6837

TRX5539
TRX6742G
TRX6742R
TRX6742X

TRX3936
4x10 BCS

TRX6739
TRX6739G
TRX6739R
TRX6739X

TRX1654
TRX1654X
TRX1985
5x8x0.5 TW
TRX5119
10x15x4 BB

TRX5116
5x11x4

TRX2579
3x15 BCS

TRX3642X
3x12 CSS

TRX6832G
TRX6832X
TRX6832A
TRX6832R
TRX6832

TRX5525

TRX3643
TRX3643G
TRX3643R
TRX3643X

TRX5525

TRX3937
4x12 BCS

TRX6723X
TRX6723R

TRX2579
3x15 BCS

TRX7461
TRX7461G
TRX7461X

TRX2579
3x15 BCS

TRX2579
3x15 BCS

TRX7461
TRX7461G
TRX7461X

TRX2577
3x10 BCS

TRX2579
3x15 BCS

TRX2754

TRX6851A
TRX6851R

TRX2579
3x15 BCS

TRX6788
TRX5119
10x15x4 BB

TRX6788
TRX5381

TRX3642X
3x12 CSS

TRX6834
28mm

TRX3655R
TRX3655A
TRX3655G
TRX3655L
TRX3655P
TRX3655T

TRX6834
52mm

TRX682X
TRX6788

TRX6788
TRX5381

TRX6788
TRX5379R
TRX5379X

TRX6788
TRX5117
6x12x4 BB

TRX6888X

TRX6881


TRX6769

TRX2579
3x15 BCS

TRX6764-BLKCR
TRX6764
TRX6773A
TRX6773G
TRX6773R
TRX6773X
TRX6792

Front Diff komplett

TRX6788



Dämpfer Montage

TRX7468
TRX7463

TRX7468

TRX7463

TRX7464T

TRX7466
TRX7466G
TRX7466A
TRX7466R

TRX7468

TRX7444

TRX7440

TRX7441

TRX7445

TRX7448

TRX7463

TRX7468

TRX7468
TRX7463

TRX7463

REV 230809-R02

See Parts List for a complete listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.



MONTAGE VORNE

RUSTLER 4x4 ULTIMATE



MONTAGE CHASSIS



Telemetrie Sensor

TRX6521 - Stecken Sie den grauen Stecker in den V/T-Steckplatz am Empfänger (TRX6533).
Beachten Sie, dass der rote Stecker zum Anschließen des Stroms vom Regler verwendet wird.



TRX6520 - Stecken Sie es in den RPM-Steckplatz am Empfänger (TRX6533).



See Parts List for a complete listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

MONTAGE ANTRIEBSWELLEN



MODULARE MONTAGE

